

CLEANING & DISINFECTING YOUR CHROMEBOOK

STEP 1: POWER OFF

Remove the charger and hold the power button for about 5-10 seconds until the screen goes dark.

STEP 2: REMOVE ANY ACCESSORIES

Unplug any attached headphones or USB accessories.

STEP 3: GENTLY WIPE THE SCREEN

Dampen a microfiber cloth with an LCD-safe solution (screen cleaner) and gently wipe the screen.

STEP 4: GENTLY WIPE THE KEYBOARD AND OUTER SHELL

A damp 70% isopropyl alcohol wipe can be used to clean the keyboard and outer shell. Allow the device to dry completely before powering it on.